



| | | | |
|-------------------------------------|--|--------------------------------------|-----------------|
| (1) <u>Nut, Speaker:</u> | LR008340 | (10) <u>Secondary Air Injection:</u> | YWB000070 |
| (2) <u>Speaker:</u> | XQM000060 | (11) <u>Steering Column:</u> | YWC000440 |
| (3) <u>Module:</u> | '02-'05 YWC000930 '06-'08 YWC000931 | (12) <u>Engine Managment:</u> | YWB000130 |
| (4) <u>Nut, Module:</u> | KTQ100020 | (13) <u>Misc.:</u> | YWB101050 |
| (5) <u>Relay, Wiper/Washer:</u> | Grey YWB000060 '05-'08 YWB000160 | (14) <u>Heated Steering Wheel:</u> | YWB000140 |
| (6) <u>Relay, Fuel Filler Door:</u> | YWB000080 | (15) <u>W/Headlamp Washer:</u> | YWB000110 |
| (7) <u>Rear Primered Set:</u> | VUB503810LML | (16) <u>Connector:</u> | YWE000010 |
| (8) <u>Front Primered Set:</u> | VUB503800LML | (17) <u>W/Heated Washer Jets:</u> | YWC000680 |
| (9) <u>Special Order Part:</u> | Call For Info | | Yellow YWE00030 |