

## Hood ('bonnet')

### Hood prop rod

Lower mount for prop rod MRC7116 Out of Stock  
(Mounts to inner fender)

Mount pin 336536

Mount clip 336535

Hinge, left (ser III) 346854

Hinge, right (ser III) 346853

Bolt for hinge (3 req per hinge) FS106167L

Hinge bushing (ser III) 346849

Rubber bump stop (2 req) 332647

(Attaches to fire wall)

### Hood Latch (Ser. II, IIA, III)


Hood pin assembly MRC6532 Out of Stock

Hood pin receiver 332400 Out of Stock

Rubbing strip 300824

(protects radiator panel from hood rubbing)

Clips, for mounting strip (10 req) 338380



## Spare tire carrier

Blind pop rivet for spare tire mounting plate  
(9 req) 78248GEN

Long bolt (2 req) 345779

Cotter pin (acts as stop for long bolt)  
3707 Out of Stock

Hold down arm, 3-1/2" leg 347262  
(fits 5-1/2" and wider rims)

Rubber pad (4 req) MRC5627 Out of Stock  
(protects hood from tire rubbing)

Nut for pad HN2005L

## Front fenders ('wings')

Outer fender panel, left 330427 Out of Stock

Outer fender panel, right, with heater hole  
347474 Out of Stock

Outer fender panel, right, no heater hole  
STC8294 Out of Stock

Front fender panel, Right, '69 on 345623

Front fender panel, Left, '69 on  
345624 Out of Stock

Head lamp bezel, '69 on 345631

## Fender to fire wall mounting bolt

Special bolt, fits ser IIA, III AM605066