


Air Induction System



- | | | | |
|--------------------------------|--------------|-----------------------------------|--------------|
| (1) <u>Air Inlet Duct:</u> | PHD500510 | (6) <u>Air Box:</u> | V6 PHB500161 |
| (2) <u>Bracket, Air Inlet:</u> | PHD000705 | (7) <u>Screw:</u> | PYP500060 |
| (3) <u>Right Angle Duct:</u> | PHD000714 | (8) <u>Sensor, Mass Air Flow:</u> | PHF000140 |
| (4) <u>Air Duct:</u> | V6 PHD000746 | (9) <u>Air Filter:</u> | PHE000112 |
| (5) <u>Grommet:</u> | V8 PHD500025 | | |
| | PJQ500012 | | |