


Rear Coil Suspension



- | | | | |
|----------------------------|-----------|--------------------------|-----------|
| (1) <u>Bumper:</u> | RNO000011 | (7) <u>Nut:</u> | FX110057 |
| (2) <u>Bushing:</u> | ROA000022 | (8) <u>Washer:</u> | RNS000031 |
| (3) <u>Washer:</u> | RNS000041 | (9) <u>Nut:</u> | FY114047 |
| (4) <u>Strut Assembly:</u> | RPD500046 | (10) <u>Isolator:</u> | RBC500011 |
| (5) <u>Buffer:</u> | RPC500013 | (11) <u>Insulator:</u> | RPF500023 |
| (6) <u>Insulator:</u> | RNE000011 | (12) <u>Coil Spring:</u> | RKB500033 |